

**+27 Años de Experiencia**

# SOLUCIONES

en Rollos de Papel



Rollo Termico

Rollo Sensibilizado

Rollo Bond



Contamos con la **MEDIDA EXACTA**  
para tus equipos de impresión

- ★ Ideal para impresiones con acabados de Alta Definición y Contraste
- ★ Nivel de Blancura y Nitidez Superior
- ★ Descuentos Especiales por Volúmen
- ★ Disponibilidad Inmediata



**TIENDA EN LINEA**

12% Descuento al usar  
codigo cupon AHORROSYS



**ENVIOS A DOMICILIO**

**ATENCION INMEDIATA**



+502 5024-1128  
+502 5608-9140

Solicita tus rollos en linea **Visita [www.e-systemedia.com](http://www.e-systemedia.com)**



## Rollos de Papel Autocopiativo / Sensibilizado

CODIGO	MODELO OEM	RENDIMIENTO	IMPRESORA
<a href="#">38MMS</a>	<a href="#">38MMS</a>	115 pies	Caja Registradora
<a href="#">44MMS</a>	<a href="#">44MMS</a>	100 pies	Caja Registradora, Samsung ER-4615, Samsung ER-5100, Samsung ER-5115, Samsung ER-5140, Samsung ER-8000, Samsung SER-6540mk11, Samsung ER-4800, Samsung ER-4900, Samsung ER-4915, Samsung ER-4940, Samsung ER-3715, Samsung ER-4100, Samsung ER-4715, Samsung ER1710, Samsung ER1805, Samsung ER1810, Samsung ER-2615, Samsung ER2100, Samsung ER2610, Samsung ER3540, Samsung ER3615, Samsung ER4615, Samsung ER4640, Samsung ER-2710, Samsung ER-2715, Samsung ER-6500, Samsung ERP-300, Samsung ERP-400, Samsung Ser-6500 MK11, Sanyo ECR365, Sanyo ECR375, Sanyo ECR460, Sanyo ECR500, Sanyo ECR550, Sanyo ECR570, Sanyo ECR600, Sanyo ECR6400, Sanyo ECR6410, Sanyo ECR6410, Sanyo ECR650, Sanyo ECR7000, Sanyo 7100, Sanyo ER-4640, Sanyo ER-4800, Sanyo ER-4900, Sanyo ER-4915, Sanyo ER-4940, Sanyo ER-5100, Sanyo ER5115, Sanyo ER-5140, Sanyo ECR360, Sharp ER-A310, Sharp ER-1910, Sharp ER-1911, Sharp ER-1911S, Sharp ER-1920, Sharp ER-1921, Sharp ER-2905, Sharp ER-3100, Sharp ER-3110, Sharp ER-3115, Sharp ER-4100, Sharp ER-4110, Sharp ER-A330, Sharp ERA-470, Sharp ERA-610, Sharp ER-1970, Sharp ER-A440, Sharp ER-A570, Sharp ER1875, Sharp ER1979, Sharp ER2370, Sharp ER2371, Sharp ER2908, Sharp ER2910, Sharp ER3600, Sharp ER3630, Sharp ER3640, Sharp ER4700, Sharp ER4710, Casio 2104ER, Casio 2202 , ER, Casio 2204ER, Casio 2302ER, Casio 2304ER, Casio 2402ER, Casio 2404ER, Casio 2408ER, Casio 3204ER, Casio 3205ER, Casio 3207ER, Casio 3400ER, Casio 3404ER, Casio 3408ER, Casio 3504ER, Casio 3508ER, Casio 4100SR, Casio 4200SR, Casio 4420ER, Casio 4430ER, Casio 6118ER, Casio 6130ER, Casio 8100ER, Casio CE2100, Casio CE2104, Casio CE2200, Casio CE2204, Casio CE2208, Casio CE2300, Casio CE2410, Casio CE2600, Casio CE3100, Casio CE3110, Casio CE3400, Casio CE3410, Casio CE3500, Casio CE3515, Casio CE3630, Casio CE3700, Casio CE3800, Casio CE3830, Casio CE4000, Casio CE4100, Casio CE4105, Casio CE4110, Casio CE4115, Casio CE4200, Casio CE4250, Casio CE4500 , Casio CE4515, Casio CE4530, Casio CE4600, Casio CE4615, Casio CE4700, Casio CE6000, Casio CE6100, Casio CE7000, Casio SA2000, Casio SA1000, Casio SA3000, Casio TK-1000, Casio TK-1100, Casio TK-1200, Casio TK-1300, Casio TK-2200, Casio TK-2300, Casio TK-2600, Casio TK-2700, Casio TK-3100, Casio TK-6500, Casio TK-6700, Casio TK-700, Casio TK-6000, Casio TK-7000, Casio TK-710, Casio TK-7500, Casio TK-2100, Casio TK-2500, Casio TK-3200, Elco Data 604, Elco Data 804, Elco Data ET-6600, Elco Data EX-300, Elco Data FX-400, Elco Data MP2, Elco Data MP3, Elco Data NT-2108, Elco Data NT-2324, Elco Data NT-3412, Elco Data NT-604 Aster FR4000, Aster GA318, Aster GA329, Aster GA330, Aster GA715, Aster GA911, Aster GA705, Aster GA716, Aster GA919, Omron RS14, Omron RS12, Omron RS16, Omron RS24, Omron RS4510, Omron RS4541, Omron RS55, Omron RS5510, Omron RS5541, Omron RS5550, Omron RS5560, Omron RS70, Omron RS85, Omron RS2010, Omron RS5540, Omron RS12-20, TEC MA1400, TEC MA1600, TEC MA1700, TEC MA1900, TEC MA2300, TEC MA45R, TEC MA516, TEC MA1040 TEC MA1100, TEC MA1190, TEC MA1350, TEC MA1450, TEC MA1650, Uniwell LX 5600, Uniwell NX 5400, Uniwell U100, Uniwell U700, Uniwell UX50, Uniwell UX60, Uniwell SX6600 Uniwell EX 560, Uniwell PX 6600, JCM Gold 100, JCM Gold 101, JCM Gold 108, JCM Gold 221L, JCM Gold 330, JCM Gold 381, JCM Gold 382, JCM Gold 3800, JCM Gold 3815, JCM Gold G223, JCM Gold G225, JCM Gold 4800, Sweda 2810, Sweda 450, Sweda L25, Sweda L2810, Toshiba FS-1450, Toshiba FS-1650, Toshiba MA-516, Toshiba MA-1650, Toshiba MA-1670



## Rollos de Papel Autocopiativo / Sensibilizado

CODIGO	MODELO OEM	RENDIMIENTO	EQUIPOS
<a href="#">56MMS</a>	<a href="#">56MMS</a>	75 pies	Caja Registradora, Bixolon SRP-275 Casio 101S, Casio 103ER, Casio 104ER, Casio 105ER, Casio 110ER, Casio 110CR, Casio 114ER, Casio 115ER Casio 116ER, Casio 117ER, Casio 120CR, Casio 120ER, Casio 130CR, Casio 140CR, Casio 160CR, Casio 168K Casio 18, Casio 180ER, Casio 210ER, Casio 220ER, Casio 230ER, Casio 240CR, Casio 240ER, Casio 800ER Casio 187, Casio 2102ER, Casio 140CR, Casio 240ER, Casio 800ER, Casio 2102ER, Elco Data CX-200, Elco Data NT-1071, Elco Data NT-1081, Elco Data NT-1104, Elco Data NT-1108, Elco Data NT-1110, Epson TM-U220, Epson TM-U220A, Epson TM-U220B, Epson TM-U220D, Epson TM-220PA, Epson TM-U220PB, OKIPOS 405 Olivetti ECR 300, Olivetti ECR 6100, Olivetti ECR 7100, Olivetti ERC 2150, Olivetti ECR 2350, Olivetti ECR 5000, Olivetti ECR 5000, Olympia CM-720, Olympia CM-725, Olympia CM-730, Olympia CM-735, Olympia CM-1688, Olympia CM-1920 Olympia CM-720, Olympia CM-730, Olympia CM-735, Olympia CM-1688, Olympia CM-1920, Olympia CM-726 Plus, Olympia CM-726, Omron RS1004, Omron RS1008, Omron RS1110, Omron RS57, Omron RS7, Sanyo ECR105, Sanyo ECR115, Sanyo ECR120, Sanyo ECR140, Sanyo ECR160, Sanyo ECR165, Sanyo ECR175, Sanyo ECR210, Sanyo ECR290, Samsung ER-150, Samsung ER-290, Samsung ER200, Samsung ER-220, Samsung ER300, Samsung SRP-275, Sharp XE-A101, Sharp XE-A102, Sharp XE-A102B, Sharp ER1077, Sharp ER1080, Sharp ER1100, Sharp ER1772S, Sharp ER-1017, Sharp ER-1700, Sharp ER-1772, Sharp XE-A110, Sharp XE-A120, Sharp XE-A130, Sharp XE-A102, Sharp ER-A170, TEC MA 2500, TEC MA156, Toshiba DRJST-50, Toshiba MA-156, Toshiba MA-186, Toshiba DRJST-70
<a href="#">70MMS</a>	<a href="#">70MMS</a>	100 pies	Caja Registradora, Bixolon SRP-275, Epson TMU950, Samsung SRP-275
<a href="#">70MMS2</a>	<a href="#">70MMS2</a>	90 pies	Caja Registradora, Bixolon SRP-275, Samsung SRP-275
<a href="#">82MMS</a>	<a href="#">82MMS</a>	85 pies	Caja Registradora
<a href="#">76MMS2</a>	<a href="#">75MMS2</a>	67 pies	Caja Registradora, Axiohm A714, Bixolon SRP-270, Bixolon SRP-275, Epson TM-300, Epson TM-U220, Epson TM-U220B, Epson TM-U220D, Epson TM-U220PD, Epson TM-U230, OKIPOS 405, Samsung SRP-275
<a href="#">76MMS</a>	<a href="#">75MMS</a>	90 pies	Caja Registradora, Axiohm A714, Bixolon SRP-270, Bixolon SRP-275, Epson TM-300, Epson TM-U220, Epson TM-U220B, Epson TM-U220D, Epson TM-U220PD, Epson TM-U230, OKIPOS 405, Samsung SRP-275
<a href="#">114MMS</a>	<a href="#">95MMS</a>	85 pies	Caja Registradora, Star Micronics DP8340, Star Micronics DP8340SM, Star Micronics DP8340 FC, Star Micronics DP8340 FM, Star Micronics DP8340 RC, Star Micronics DP8340 RM, Star Micronics SP 8340FD



## Rollos de Papel Térmico

CODIGO	MODELO OEM	RENDIMIENTO	EQUIPOS
<a href="#">38MMT</a>	<a href="#">38MM</a>	165 pies	Caja Registradora, Sam4S 5200, Sam4S 5240, Sharp 212, Sharp 213, Sharp 303, Casio, Elco Data, Lewin Samsung 5200, Samsung 5240
<a href="#">2.25Tpos</a>	<a href="#">56MM</a>	50 pies	Clover Flex Mobile POS, Clover Mini, Axalto Magic X1000 Blue Bamboo Model P25 Portable Printer, Blue Bamboo Model H50 Wirelss POS Terminal, CelereX CX 1000 Remote Terminal, Citizen CBM262, Citizen CBM270 EBW, Auto Stik 950 0 EMCO Wheaton Tank Monitor II Extch S1500T, S2500THS First Data FD400 Terminal de tarjeta de crédito Hypercom I.C.E.4000, Hypercom I.C.E.4000CE, Hypercom I.C.E.5000, Hypercom I.C.E.5500, Hypercom I.C.E.6500, Hypercom T7P-T
<a href="#">2.25T</a>	<a href="#">57MM</a>	80 pies	Casio CE-T100, Casio CX 1000, Casio PCR-T465, Casio PCR-T2000, Casio SE-S300, Casio SE-S400, Casio SE-C300, Casio SE-C450, Casio SE-S10, Casio SE-S2000, Casio SE-S3000, Casio SE-C2000, Casio SE-C3500, Casio SE-S6000, Casio SE-C6000, Casio SE-G1, Casio TE-100, Casio TE-2000, Casio TE-2200, Casio TE-2400, Casio TE-3000S, Casio TE-4000F, Casio TE-4500, Casio TE-7000S, Casio TE-8000F, Casio TE-M80, Casio TK-T200, Casio TK-T500, Casio TE-2000, Casio TE-3000, Casio TE-4500, Casio TE-7000, Casio TE-8500, Citizen CBM262, Citizen CBM270, Citizen CT-S280, Citizen CT-S281, Citizen CT-S310II, Epson TM-P60 Epson TM-T88IV, Epson TM-T88V, Epson TM-T88V-i, Epson M129H, Epson TM-T20, Epson TM-T20II, Royal Alpha 583CX, Royal Alpha 600SC, Royal Alpha 9155SC, Sam4s ER-5215M, Samsung ER-650, Samsung ER-650R, Samsung ER-650SS, Samsung ER-5200, Samsung ER-5215, Samsung ER-5240, ECR Sampos ER 057, ECR Sampos ER 060, ECR Sampos ER-159, ECR Sampos TH-582, Elco Data AX-100, Elco Data AX-110, Elco Data CR-115, Ingenico i5300, Ingenico Ipp480, Metapace T4, NCR 7197, OKIPOS PT330, OKIPOS T390, OKIPOS 406, OKIPOS 407, Olivetti ECR-6700, Olivetti ECR-6800, Olivetti ECR-7700, Olivetti ECR-8200S, Olivetti ECR-8220, SAM4S Ellix-10, SAM4S Ellix-20, SAM4S Ellix-30, SAM4S Ellix-40, Sharp XE-A113, Sharp XE-A213, Sharp XE-A303, Sharp UP-700, Uniwell EX570, Uniwell EX575, Uniwell LEX5700, Uniwell LX5750, Uniwell PX6700
<a href="#">3.125T</a>	<a href="#">80MM</a>	220 pies	Axiohm TELESTO, Axiohm APOS Premium II, Axiohm A715, Axiohm A721, Axiohm A756, Axiohm A758, Axiohm A793, Axiohm A794, Axiohm Astrium, Axiohm A716, Axiohm TPG-A795, Axiohm TPG A760, Bixelon SRP-350, Bixelon SRP-350II, Bixelon SRP-350 PLUS, Bixelon SRP-350 PLUS II, Bixelon SRP-370, Bixelon SRP-F310, Bixelon SRP-F312, Bixelon SRP-352, Bixelon SRP-372, Bixelon SRP-370, Bixelon STP-131, Bizerba KHII100, Bizerba KHII200, Bizerba KHII400, Bizerba KHII800, Casio UP-360, Citizen CT-S300, Citizen CT-S2000, Citizen CT-S300, Citizen CT-S4000, Citizen CBM-1000, Citizen CBM-230, Citizen CBM-231, Citizen CBM-232, Citizen CBM-233, Citizen LT-380, Citizen IDP310, Citizen IDP3210, Citizen DP3221, Citizen IDP3310, Citizen CBM1000, Citizen CBM230, Citizen CBM232, Citizen CBM233, Citizen CBM253, Citizen CBM1000, Citizen CBM8000, Citizen CT-S300, Citizen CT-S310II, Citizen iDP-3210, Citizen iDP-3221, Citizen iDP-3310, Epson TM-H5000, Epson TM-T88 III, Epson TM-T90, Axiohm DT-50, Epson M129B, Epson TM-T88IV, Epson TM-T70, Epson M129B, Epson M129C, Epson M129H, Epson M225A, Epson M-T301, Epson T301A, Epson TM-881, Epson TM-8811, Epson TM-H5000II, Epson TM-H6000, Epson TM-H6000II, Epson TM-T20, Epson TM-T20II, Epson TM-T80, Epson TM-T85, Epson TM-T88, Epson TM-T88V-i, Epson TM-T90, Epson TM-T900, Epson TM-L90, Epson TM-883, NCR 7197, OKIPOS 406, OKIPOS 407, OKIPOS 408, OKIPOS 410, OKIPOS PT330, OKIPOS PT390, Sam4s Ellix-20, Sam4s Elix-30, Sam4s Ellix-40, Samsung SRP-350, Samsung SPS-1000, Seypos PRP-85IV, Seypos PRP-90, Seypos PRP-300, Seypos 562, Sharp MTP401, Sharp STP312, Sharp UT80BP, Sharp UP-810F, Sharp UP-820F, Sharp UP-800, Sharp UP-820N, Sharp UP-811F, Star Micronics DT-X10, Star Micronics NP-325, Star Micronics NP-326, Star Micronics TSP 1000, Panasonic 5000, Panasonic JS-5100, Panasonic JS-7000, Panasonic JS-7500, Uniwell SX8505, Uniwell Tyso SX7505, Uniwell PX-6750
<a href="#">4.25T</a>	<a href="#">109MM</a>	115 pies	Ithaca Peripherals 200, 250 Sable CT90, Samsung SRP 300, Samsung SRP 350, Red Jacket ST1400, Remanco 1500, Seiko DP400 STP411, Bixelon SPP-R400, Datamax Apex 4, OKIPOS 408
<a href="#">75MMT</a>	<a href="#">76MM</a>	50 pies	Datamax Oneill Oc3, Zebra QI 320



## Rollos de Papel Bond

CODIGO	MODELO OEM	RENDIMIENTO	EQUIPOS
<a href="#">44MM</a>	<a href="#">44MM</a>	150 pies	<p>Caja Registradora, Samsung ER-4615, Samsung ER-5100, Samsung ER-5115, Samsung ER-5140, Samsung ER-8000, Samsung SER-6540, Samsung ER-4800, Samsung ER-4900, Samsung ER-4915, Samsung ER-4940, Samsung ER-3715, Samsung ER-4100, Samsung ER-4715, Samsung ER1710, Samsung ER1805, Samsung ER1810, Samsung ER-2615, Samsung ER2100, Samsung ER2610, Samsung ER3540, Samsung ER3615, Samsung ER4615, Samsung ER4640, Samsung ER-2710, Samsung ER-2715, Samsung ER-6500, Samsung ERP-300, Samsung ERP-400, Samsung Ser-6500 MK11, Sanyo ECR365, Sanyo ECR375, Sanyo ECR460, Sanyo ECR500, Sanyo ECR550, Sanyo ECR570, Sanyo ECR600, Sanyo ECR6400, Sanyo ECR6410, Sanyo ECR6410, Sanyo ECR650, Sanyo ECR7000, Sanyo 7100, Sanyo ER-4640, Sanyo ER-4800, Sanyo ER-4900, Sanyo ER-4915, Sanyo ER-4940, Sanyo ER-5100, Sanyo ER-5115, Sanyo ER-5140, Sanyo ECR360, Sharp ER-A310, Sharp ER-1910, Sharp ER-1911, Sharp ER-1911S, Sharp ER-1920, Sharp ER-1921, Sharp ER-2905, Sharp ER-3100, Sharp ER-3110, Sharp ER-3115, Sharp ER-4100, Sharp ER-4110, Sharp ER-A330, Sharp ERA-470, Sharp ERA-610, Sharp ER-1970, Sharp ER-A440, Sharp ER-A570, Sharp ER1875, Sharp ER1979, Sharp ER2370, Sharp ER2371, Sharp ER2908, Sharp ER2910, Sharp ER3600, Sharp ER3630, Sharp ER3640, Sharp ER4700, Sharp ER4710, Casio 2104ER, Casio 2202ER, Casio 2204ER, Casio 2302ER, Casio 2304ER, Casio 2402ER, Casio 2404ER, Casio 2408ER, Casio 3204ER, Casio 3205ER, Casio 3207ER, Casio 3400ER, Casio 3404ER, Casio 408ER, Casio 3504ER, Casio 3508ER, Casio 4100SR, Casio 4200SR, Casio 4420ER, Casio 4430ER, Casio 6118ER, Casio 6130ER, Casio 8100ER, Casio CE2100, Casio CE2104, Casio CE2200, Casio CE2204, Casio CE2208, Casio CE2300, Casio CE2410, Casio CE2600, Casio CE3100, Casio CE3110, Casio CE3400, Casio CE3410, Casio CE3500, Casio CE3515, Casio CE3630, Casio CE3700, Casio CE3800, Casio CE3830, Casio CE4000, Casio CE4100, Casio CE4105, Casio CE4110, Casio CE4115, Casio CE4200, Casio CE4250, Casio CE4500, Casio CE4515, Casio CE4530, Casio CE4600, Casio CE4615, Casio CE4700, Casio CE6000, Casio CE6100, Casio CE7000, Casio SA2000, Casio SA1000, Casio SA3000, Casio TK-1000, Casio TK-1100, Casio TK-1200, Casio TK-1300, Casio TK-2200, Casio TK-2300, Casio TK-2600, Casio TK-2700, Casio TK-3100, Casio TK-6000, Casio TK-6500, Casio TK-6700, Casio TK-700, Casio TK-7000, Casio TK-710, Casio TK-7500, Casio TK-2100, Casio TK-2500, Casio TK-3200, Elco-Data 604, Elco-Data 804, Elco-Data ET-6600, Elco-Data EX-300, Elco-Data FX-400, Elco-Data MP2, Elco-Data MP3, Elco-Data NT-2108, Elco-Data NT-2324, Elco-Data NT-3412, Elco-Data NT-604</p> <p>Aster FR4000, Aster GA318, Aster GA329, Aster GA330, Aster GA715, Aster GA911, Aster GA705, Aster GA716, Aster GA919, Omron RS14, Omron RS12, Omron RS16, Omron RS24, Omron RS4510, Omron RS4541, Omron RS55, Omron RS5510, Omron RS5541, Omron RS5550, Omron RS5560, Omron RS70, Omron RS85, Omron RS2010, Omron RS5540, Omron RS12-20, TEC MA1400, TEC MA1600, TEC MA1700, TEC MA1900, TEC MA2300, TEC MA45R, TEC MA516, TEC MA1040, TEC MA1100, TEC MA1190, TEC MA1350, TEC MA1450, TEC MA1650, Uniwell LX 5600, Uniwell NX 5400, Uniwell U100, Uniwell U700, Uniwell UX50, Uniwell UX60, Uniwell SX6600, Uniwell EX 560, Uniwell PX 6600, JCM Gold 100, JCM Gold 101, JCM Gold 108, JCM Gold 221L, JCM Gold 330, JCM Gold 381, JCM Gold 382, JCM Gold 3800, JCM Gold 3815, JCM Gold G223, JCM Gold G225, JCM Gold 4800, Sweda 2810, Sweda L25, Sweda L2810, Toshiba FS-1450, Toshiba FS-1650, Toshiba MA-516, Toshiba MA-1650, Toshiba MA-1670, Uniwell EX-560, Uniwell LX-5600</p>
<a href="#">2.25N</a>	<a href="#">57MM</a>	100 pies	<p>Caja Registradora, Casio 101S, Casio 103ER, Casio 104ER, Casio 105ER, Casio 110ER, Casio 110CR, Casio 114ER, Casio 115ER, Casio 116ER, Casio 117ER, Casio 120CR, Casio 120ER, Casio 130CR, Casio 140CR, Casio 160CR, Casio 168K, Casio 180, Casio 180ER, Casio 210ER, Casio 220ER, Casio 230ER, Casio 240CR, Casio 240ER, Casio 800ER, Casio 187, Casio 2102ER, Casio 140CR, Elco Data CX-200, Elco Data NT-1071, Elco Data NT-1081, Elco Data NT-1104, Elco Data NT-1108, Elco Data NT-1110, Epson TM-U220, Epson TM-U220B, Epson TM-U220D, Epson TM-U220PD, Epson TM-U200, OKIPOS 405, Olivetti ECR 300, Olivetti ECR 6100, Olivetti ECR 7100, Olivetti ERC 2150, Olivetti ECR 2350, Olivetti ECR 5000, Olivetti ECR 5000, Olympia CM-720, Olympia CM-725, Olympia CM-730, Olympia CM-735, Olympia CM-1688, Olympia CM-1920, Olympia CM-720, Olympia CM-730, Olympia CM-735, Olympia CM-1688, Olympia CM-1920, Olympia CM-726 Plus, Olympia CM-726, Omron RS1004, Omron RS1008, Omron RS1110, Omron RS57, Omron RS7, Sanyo ECR105, Sanyo ECR115, Sanyo ECR120, Sanyo ECR140, Sanyo ECR160, Sanyo ECR165, Sanyo ECR175, Sanyo ECR210, Sanyo ECR290, Samsung ER-15, Samsung ER-290, Samsung ER200, Samsung ER-220, Samsung ER300, Samsung SRP-275, Sharp XE-A101, Sharp XE-A102, Sharp XE-A102B, Sharp ER1077, Sharp ER1080, Sharp ER1100, Sharp ER1772S, Sharp ER-1017, Sharp ER-1700, Sharp ER-1772, Sharp XE-A110, Sharp XE-A120, Sharp XE-A130, Sharp XE-A102, Sharp ER-A170, TEC MA 2500, TEC MA156, Toshiba DRJST-50, Toshiba MA-156, Toshiba MA-186, Toshiba DRJST-70</p>
<a href="#">2.75N</a>	<a href="#">70MM</a>	150 pies	<p>Caja Registradora, Bixolon SRP-275, Samsung SRP-275, Epson TM-U220, Epson TM-U220B, Epson TM-U220D, Epson TM-U220PD, Epson TM-U950</p>
<a href="#">3.00NA</a>	<a href="#">76MM</a>	150 pies	<p>Caja Registradora, Axiohm A714, Bixolon SRP-270, Bixolon SRP-275, Bixolon SRP-500, Epson TM-300, Epson TM-U230, Epson TM-U220, Epson TM-U220B, Epson TM-U220D, Epson TM-U220PD, OKIPOS 405, Samsung SRP-275</p>



## Rollos de Papel para Plotteadora

CODIGO	MODELO OEM	RENDIMIENTO	IMPRESORA
<a href="#">PTB 1839</a>	<a href="#">C3859A</a>	150 pies	TechJet 175i, TechJet 5500, TechJet 5536 Series, Encad CADJET 2, Encad CADJET 3D, Encad CADJET T-200, Encad NovaJet I, Encad NovaJet II, Encad NovaJet III, Encad NovaJet IV, Encad NovaJet Pro, HP DesignJet 1050c, HP DesignJet 1050c Plus,, HP DesignJet 1055c Plus, HP DesignJet 1055cm, HP DesignJet 230, HP DesignJet 250c, HP DesignJet 350c, HP DesignJet 430, HP DesignJet 450c, HP DesignJet 455ca, HP DesignJet 488ca, HP DesignJet 500, HP DesignJet 500ps, HP Designjet 600, HP DesignJet 650, HP DesignJet 650c, HP DesignJet 700, HP DesignJet 750C, HP DesignJet 750C Plus, HP DesignJet 750CM, HP DesignJet 755cm, HP DesignJet 800, HP DesignJet 800ps, Xerox 2230ij
<a href="#">PTB 1824</a>	<a href="#">C3860A</a>	150 pies	HP DesignJet 1050c, HP DesignJet 1050c Plus, HP DesignJet 1055c Plus, HP DesignJet 1055cm, HP DesignJet 230, HP DesignJet 250c, HP DesignJet 350c, HP DesignJet 430, HP DesignJet 450c, HP DesignJet 455ca, HP DesignJet 488ca, HP DesignJet 500, HP DesignJet 500ps, HP Designjet 600, HP DesignJet 650, HP DesignJet 650c, HP DesignJet 700, HP DesignJet 750C, HP DesignJet 750C Plus, HP DesignJet 750CM, HP DesignJet 755cm, HP DesignJet 800, HP DesignJet 800ps, Xerox 2230ij
<a href="#">PL 2024</a>	<a href="#">C3851A</a>	150 pies	HP DesignJet 1050c, HP DesignJet 1050c Plus, HP DesignJet 1055c Plus, HP DesignJet 1055cm, HP DesignJet 230, HP DesignJet 250c, HP DesignJet 350c, HP DesignJet 430, HP DesignJet 450c, HP DesignJet 455ca, HP DesignJet 488ca, HP DesignJet 500, HP DesignJet 500ps, HP Designjet 600, HP DesignJet 650, HP DesignJet 650c, HP DesignJet 700, HP DesignJet 750C, HP DesignJet 750C Plus, HP DesignJet 750CM, HP DesignJet 755cm, HP DesignJet 800, HP DesignJet 800ps, Xerox 2230ij
<a href="#">PV 2024</a>	<a href="#">C3862A</a>	150 pies	HP DesignJet 1050c, HP DesignJet 1050c Plus, HP DesignJet 1055c Plus, HP DesignJet 1055cm, HP DesignJet 230, HP DesignJet 250c, HP DesignJet 350c, HP DesignJet 430, HP DesignJet 450c, HP DesignJet 455ca, HP DesignJet 488ca, HP DesignJet 500, HP DesignJet 500ps, HP Designjet 600, HP DesignJet 650, HP DesignJet 650c, HP DesignJet 700, HP DesignJet 750C, HP DesignJet 750C Plus, HP DesignJet 750CM, HP DesignJet 755cm, HP DesignJet 800, HP DesignJet 800ps, Xerox 2230ij
<a href="#">PL 2036</a>	<a href="#">C3850A</a>	150 pies	HP DesignJet 1050c, HP DesignJet 1050c Plus, HP DesignJet 1055c Plus, HP DesignJet 1055cm, HP DesignJet 230, HP DesignJet 250c, HP DesignJet 350c, HP DesignJet 430, HP DesignJet 450c, HP DesignJet 455ca, HP DesignJet 488ca, HP DesignJet 500, HP DesignJet 500ps, HP Designjet 600, HP DesignJet 650, HP DesignJet 650c, HP DesignJet 700, HP DesignJet 750C, HP DesignJet 750C Plus, HP DesignJet 750CM, HP DesignJet 755cm, HP DesignJet 800, HP DesignJet 800ps, Xerox 2230ij
<a href="#">PV 2036</a>	<a href="#">C3861A</a>	150 pies	HP DesignJet 1050c, HP DesignJet 1050c Plus, HP DesignJet 1055c Plus, HP DesignJet 1055cm, HP DesignJet 230, HP DesignJet 250c, HP DesignJet 350c, HP DesignJet 430, HP DesignJet 450c, HP DesignJet 455ca, HP DesignJet 488ca, HP DesignJet 500, HP DesignJet 500ps, HP Designjet 600, HP DesignJet 650, HP DesignJet 650c, HP DesignJet 700, HP DesignJet 750C, HP DesignJet 750C Plus, HP DesignJet 750CM, HP DesignJet 755cm, HP DesignJet 800, HP DesignJet 800ps, Xerox 2230ij
<a href="#">PV 1624</a>	<a href="#">PV 1624</a>	150 pies	HP DesignJet 1050c, HP DesignJet 1050c Plus, HP DesignJet 1055c Plus, HP DesignJet 1055cm, HP DesignJet 230, HP DesignJet 250c, HP DesignJet 350c, HP DesignJet 430, HP DesignJet 450c, HP DesignJet 455ca, HP DesignJet 488ca, HP DesignJet 500, HP DesignJet 500ps, HP Designjet 600, HP DesignJet 650, HP DesignJet 650c, HP DesignJet 700, HP DesignJet 750C, HP DesignJet 750C Plus, HP DesignJet 750CM, HP DesignJet 755cm, HP DesignJet 800, HP DesignJet 800ps, Xerox 2230ij
<a href="#">PV 1636</a>	<a href="#">PV 1636</a>	150 pies	HP DesignJet 1050c, HP DesignJet 1050c Plus, HP DesignJet 1055c Plus, HP DesignJet 1055cm, HP DesignJet 230, HP DesignJet 250c, HP DesignJet 350c, HP DesignJet 430, HP DesignJet 450c, HP DesignJet 455ca, HP DesignJet 488ca, HP DesignJet 500, HP DesignJet 500ps, HP Designjet 600, HP DesignJet 650, HP DesignJet 650c, HP DesignJet 700, HP DesignJet 750C, HP DesignJet 750C Plus, HP DesignJet 750CM, HP DesignJet 755cm, HP DesignJet 800, HP DesignJet 800ps, Xerox 2230ij
<a href="#">PL-2042</a>	<a href="#">Q1398A</a>	150 pies	HP DesignJet 1050c, HP DesignJet 1050c Plus, HP DesignJet 1055c Plus, HP DesignJet 1055cm, HP DesignJet 230, HP DesignJet 250c, HP DesignJet 350c, HP DesignJet 430, HP DesignJet 450c, HP DesignJet 455ca, HP DesignJet 488ca, HP DesignJet 500, HP DesignJet 500ps, HP Designjet 600, HP DesignJet 650, HP DesignJet 650c, HP DesignJet 700, HP DesignJet 750C, HP DesignJet 750C Plus, HP DesignJet 750CM, HP DesignJet 755cm, HP DesignJet 800, HP DesignJet 800ps, Xerox 2230ij
<a href="#">430C36L</a>	<a href="#">430C36L</a>	150 pies	Dietzegen 636SR , Dietzegen DP-36, Dietzegen DP-3610, Dietzegen DP-3630, Dietzegen DP-4200, Screen 36, Starprint 2000, Starprint 2710, Starprint 3000, Starprint 4000, Starprint 5000, Starprint 6000, Starprint 8000, Starprint 9000, Starprint 9020